

Warning

Designed for older than 15 years, it is not a toy. The model contains small parts that could be swallowed by children or inhaled. Operate under constant supervision, the model is not intended for commercial use.

Zimo MX637 Plux22 decoder function

- F0** - position lights white, switching automatically according to the direction of travel
- F1** - position lights red, switching automatically according to the direction of travel
- F2** - full beam headlight, automatic switching according to the direction of travel
- F3** - shunting mode
- F4** - switch off motor curves
- F5** - cab lighting
- F6** - engine room lighting

Placing the analog jumper and decoder in the socket

PluX 22 decoder:

Remove the decoder by gradually rocking it slightly.

